


MILLING CUTTER RZ-150 ASSEMBLING INSTRUCTIONS

This RZ-150 milling cutter screwing process is different from other milling cutter models.

Please follow instructions carefully.



To screw on RZ-150 cutter, place it opposite to the shaft and press softly against thread.



While holding the cutter with one hand, turn the shaft with the spanner following the direction of arrow as shown on picture. Repeat this movement twice or three times until shaft thread has entered the cutter. Continue screwing on the cutter with the hand as usual.